


## 5" DISPLAY SCREEN OVERVIEW



8 - Coolant Pump 1 Fault
Determine by sound or touch if the glycol pump is running. If the pump is running but is noisy, check the glycol level. If the pump is not running, check wiring connector at pump.

ALARM POP-UP THAT CAN OCCUR ON ANY SCREEN

TAP TO RE-SET AND RETURN TO PREVIOUS SCREEN



## 3.5" DISPLAY SCREEN OVERVIEW

