
BLUE SEA SYSTEMS

CableClam Installation Instructions PN 1007100

- 1. Run cable through center hole of gasket.
- 2. Fit cable into deck ring groove.
- 3. Fasten deck ring and gasket to the surface by tightening each screw a few turns at a time. Do not over-tighten screws.
- 4. Press the stainless steel cap over assembly. Line up the groove in cap with cable.



Blue Sea Systems Bellingham, WA 98226 USA p 360.738.8230 p 800.222.7617 USA and Canada f 360.734.4195 conductor@bluesea.com www.bluesea.com