



DIMENSIONS ARE SHOWN IN INCH AND [MILLIMETERS]

THIS TEMPLATE HAS BEEN PROVIDED TO HELP YOU IN INSTALLING YOUR NEW BLUE SEA SYSTEMS 12 POSITION POWER DISTRIBUTION PANEL.



425 Sequoia Drive Bellingham, WA 98226  
 Phone (360)738-8230 Fax (360)734-4195

PANEL CUTOUT DIMENSIONS FOR 12 POSITION PANELS

DATE	SCALE	DOCUMENT NO.	REVISION	SHEET
1-28-04	N.T.S.	6672-B	B	1 OF 1